
Training aid only, not flight instruction. Review it with your CFI and get their approval before you use it in training or in the airplane. Check every number against the POH and current FAA sources. Last reviewed Nov 15, 2026 against the FAA Chart Supplement effective Oct 29, 2026 and the Cessna 172N and 172P POHs.

KONZ RUNWAY 22 PATTERN: CESSNA 172

Cessna 172N and 172P · Pattern work · Grosse Ile Municipal (KONZ)

THE PATTERN

CTAF 123.0 · AWOS 119.675 · Field 591 MSL · TPA 1,600 MSL (standard 1,000 AGL; none published)



© 2026 FLY Aviation, LLC · Training aid only, not flight instruction

Pattern rules at KONZ

- **Left traffic** Runway 22. **Right traffic** Runway 4: see the 172 Runway 4 pattern. Runway 17/35 is closed.
- **Displaced threshold:** Runway 22's landing threshold is 428 ft in from the end. Touch down past the threshold bar.
- **PAPIs:** reported inoperative. Check the NOTAMs and fly your own glidepath.
- Enter on the **45° to midfield downwind**, already at pattern altitude.
- Turn crosswind within 300 ft of pattern altitude, about **700 AGL**.
- Listen to AWOS (119.675) about 10 miles out. Make your first CTAF call before you get there.
- Birds, deer, coyotes and waterfowl on and near the field. Loose concrete near the closed runway.
- **High wing:** the wing hides traffic on the inside of every turn. Raise the wing slightly and look before you turn base and final.
- **Carb heat:** ON abeam, before you reduce power, and left ON to touchdown. OFF at once in a go-around.
- Ultralights and powered parachutes fly nearby. Keep looking outside.

© 2026 FLY Aviation, LLC · Training aid only, not flight instruction

LEG BY LEG

Knots indicated · RPM approximate · Radio on CTAF 123.0

E	**Inbound, 45° entry** RPM ~2,200 Flaps up. Mixture rich. Carb heat as needed. *"Grosse Ile traffic, Cessna [tail], five miles south, inbound to land, will enter left downwind Runway 22, Grosse Ile."*	**90**
1	**Takeoff roll** RPM ~2,300–2,400 static Flaps up, carb heat COLD, mixture rich, full throttle. *"Grosse Ile traffic, Cessna [tail], departing Runway 22, left closed traffic, Grosse Ile."*	**Rotate 55**
2	**Climbout** RPM Full Flaps up.	**73 (N) · 76 (P)**
3	**Crosswind** RPM Full Flaps up. *"Cessna [tail], left crosswind Runway 22."*	**73 (N) · 76 (P)**
4	**Downwind** RPM ~2,200 Fuel selector BOTH, mixture rich, landing light on. *"Cessna [tail], left downwind Runway 22, touch-and-go" (or "full stop").*	**90**

© 2026 FLY Aviation, LLC · Training aid only, not flight instruction

5	**Abeam the threshold** RPM ~1,500 **Carb heat ON. Flaps 10** (below 85).	**75**
6	**Base turn** RPM ~1,500 **Flaps 20.** *"Cessna [tail], left base Runway 22."*	**70**
7	**Turn final** RPM As needed **Flaps 30.** (172N: 30, or 40 if your CFI teaches it.) *"Cessna [tail], final Runway 22, full stop."*	**65**
8	**Short final** RPM As needed Carb heat stays ON.	**60–65 over the fence**
9	**Flare and rollout** RPM Idle After exit: flaps up, carb heat COLD. *"Cessna [tail], clear of Runway 22, Grosse Ile."*	**Mains first**
GA	**Go-around** RPM Full Full throttle, **carb heat COLD, flaps 20** right away. Flaps 10 once climbing, then up above 60 at a safe height. *"Cessna [tail], going around Runway 22."*	**55, then 60+**

© 2026 FLY Aviation, LLC · Training aid only, not flight instruction

KEY NUMBERS

Our planning numbers · verify in your 172 POH

Rotate **55**	**Climb (Vy)** **73 N · 76 P**
Downwind **90 · 2,200**	**Abeam** **75 · flaps 10**
Base **70 · flaps 20**	**Final** **65 · flaps 30**
Over the fence **60–65**	**Pattern altitude** **1,600 MSL**

Knots indicated. 172N flaps go to 40°, all below 85 KIAS. 172P flaps go to 30°: up to 10° below 110 KIAS, more than 10° below 85. Vy at sea level is 73 in the 172N and 76 in the 172P. Approach speeds in the handbooks: 172N 55–65 with flaps down, 172P 60–70; 60–65 over the fence fits both. These are our planning numbers; check them against the POH and placards in your airplane.

© 2026 FLY Aviation, LLC · Training aid only, not flight instruction

PRE-LANDING CHECK AND FLOW

Say it out loud on every downwind

GUMPS, Cessna 172 version

- Gas: fuel selector BOTH, quantity checked. No fuel pump to switch.
- Undercarriage: fixed gear, nothing to lower. Say it anyway; the habit matters later.
- Mixture: RICH. **Carb heat ON** before you reduce power.
- Prop: fixed pitch. Watch RPM instead.
- Switches and seatbelts: landing light on, belts and harnesses snug, doors latched.

The flow at a glance

- **Takeoff:** full throttle, carb heat cold, rotate 55, climb at 73 (N) or 76 (P).
- **Crosswind** at 700 AGL. **Downwind** level at 1,600, 90 knots, about 2,200 RPM.
- **Abeam:** carb heat ON, power 1,500, flaps 10, 75 knots.
- **Base:** flaps 20, 70 knots. **Final:** flaps 30, 65 knots.
- **Fence:** 60–65. Carb heat stays on; off after landing.

© 2026 FLY Aviation, LLC · Training aid only, not flight instruction

STABILIZED-APPROACH GATES

If any gate is missed, go around

500 AGL

Flaps 30, 65 knots, on the glidepath, trimmed.

300 AGL

Stable, or go around. Only small power corrections from here.

Fence

60–65 knots. The aim point is not moving in the windshield.

Training aid only, not flight instruction. Speeds and RPM are our own planning numbers in knots for a carbureted Cessna 172N or 172P; verify every one against the POH and placards in the airplane you fly, and fly the profile your CFI teaches. Check pattern altitude, traffic direction and frequencies in the current Chart Supplement and NOTAMs before you fly.

© 2026 FLY Aviation, LLC · Training aid only, not flight instruction